


Bæreevnekurve LBE




LBE 66/22 simpel

LBE 66/22 kontinuerlig

LBE 50/22 simpel

LBE 50/22 kontinuerlig




LBE 66/27 simpel

LBE 66/27 kontinuerlig

LBE 50/27 simpel

LBE 50/27 kontinuerlig




LBE 66/32 simpel

LBE 66/32 kontinuerlig

LBE 50/32 simpel

LBE 50/32 kontinuerlig



LBE 66/40 simpel

LBE 66/40 kontinuerlig

LBE 50/40 simpel

LBE 50/40 kontinuerlig